

Português

HEADSET GAMER SEM FIO

HZ-K21



RECURSOS

- 1 + 3 pressione o botão "+" no musicstate para aumentar o volume pressione o botão "-" no estado de música para diminuir o volume pressione brevemente a posição intermediária no estado de música para pausar logotipo retroiluminado vermelho (indicação de funcionamento e carga)
- 2 transmissor de microfone
- 4 porta de carregamento USB
- 6 liga / desliga
- 7 entrada de linha (quando o fone de ouvido estiver sem energia, conecte o cabo de áudio para usar como fone de ouvido com fio)
- 8 microfone ligado / desligado

INSTALAÇÃO

- 1. Ligar: Coloque o botão liga / desliga no estado "LIGADO", o fone de ouvido se estiver ligado, o indicador de energia acenderá e piscará. Este estado significa que o transmissor USB não está conectado e espere para ser conectado.
  - 2. Conecte o transmissor USB diretamente na porta USB do dispositivo. Então o indicador do transmissor e os fones de ouvido estão sempre ligados. Indique que eles estão conectados com sucesso.
  - 3. Desligar: coloque o botão liga / desliga na posição "Desligado", o fone de ouvido a energia estiver desligada, o indicador de energia do fone de ouvido apagará e economize a energia da bateria ao máximo.
- Nota: O transmissor deve estar longe da rede sem fio cartão, dispositivo BT, outros dispositivos de 2,4 GHz.

CARREGANDO BATERIAS

A bateria do fone de ouvido não está totalmente carregada quando sai da fábrica. Portanto, carregue totalmente o fone de ouvido para 10 horas antes do uso. Para a próxima carga, leva apenas cerca de 3,5 horas para carregar totalmente. O cabo de carregamento deve ser conectado ao fone de ouvido, carregando, o indicador do bit emissor de luz está sempre ligado e quando está totalmente carregado, o indicador apaga-se. Ao ouvir um "BEEP" enquanto usa o fone de ouvido, você está lembrando que a bateria está fraca e precisa ser recarregada. Quando você não usa o fone de ouvido por um longo tempo, a bateria pode causar descarga excessiva. Você deve carregar o fone de ouvido por mais de 4 horas, mas não mais de 24 horas. Nota: alguns carregadores também podem vir com uma porta USB que permite que o fone de ouvido seja carregado com um carregador de 5V 1000 MA. Mas por favor não exceda este valor, caso contrário, será facilmente danificar o fone de ouvido.

AJUSTE DA CABEÇA

Ajuste livremente os slots retráteis do cartão em ambos os lados antes vestindo, o que o torna mais confortável e fácil.

MICROFONE

Design de microfone omnidirecional de alta qualidade oculto, que pode ser dobrado para trás sem ocupar espaço durante o uso.

CONDIÇÕES DE TRANSPORTE

É proibido jogar ou derrubar mercadorias. se a mercadoria estiver em um local com alta umidade, é recomendado o uso de capas protetoras contra umidade, proibido colocar mais de 4 peças de embalagens no topo de cada um.

Este dispositivo atende aos requisitos básicos e outras condições relevantes das Diretivas Europeias apropriadas

Este dispositivo está em conformidade com a Parte 15 das Regras da Comissão FCC. Uma operação está sujeita às seguintes duas condições:  
(1). Este dispositivo não pode causar interferência prejudicial (2). Este dispositivo deve aceitar qualquer interferência recebida, incluindo interferência que pode causar ação indesejável.

Este símbolo indica que o produto não deve ser tratado como lixo doméstico. Deve ser entregue ao responsável centro de coleta para a reciclagem de equipamentos elétricos e eletrônicos, ou devolvidos ao fornecedor para descarte.

Restrição de substâncias perigosas (chumbo, mercúrio, cromo hexavalente, cádmio, bifenilos polibromados, éter difenílico polibromado).



SOLUÇÃO DE PROBLEMAS

- 1. Headset sem som
  - verifique a conexão entre o fone de ouvido e o transmissor e conecte o transmissor em outra porta USB no computador feche e reabra o reproduzidor multimídia
  - verifique se a energia é insuficiente e use-a após o carregamento
- 2. A luz indicadora do transmissor pisca lentamente e o fone de ouvido Sem som
  - reconecte o transmissor, quando o fone de ouvido estiver ligado, pressione e segure o botão do meio no fone de ouvido (3) por mais de 5 segundos, o indicador luminoso piscando rapidamente e em o estado de configuração de fábrica. Quando o fone de ouvido emitir luz indicador mantenha a luz acesa Pode ser usado normalmente
- 3. Curta distância de recebimento
  - verifique se há interferência na placa de rede sem fio, por favor mantenha o transmissor longe de interferências sem fio verifique se há, ou seja, equipamento do mesmo ninho de frequência para o transmissor, evite o mesmo equipamento frequency a distância de recebimento está relacionada ao meio ambiente e o distangy pode ser afetado em alguns ambientes
- 4. O volume está muito alto
  - reduza o volume devido à configuração do PC ou outro dispositivo portátil

CONTEÚDO DO PACOTE

1 fone de ouvido para jogos sem fio H4, 1 x transmissor USB, 1 x micro Cabo de carregamento USB, cabo de áudio 1 x 3,5 mm, manual do usuário 1 X

**NÃO ABRA UMA RECLAMAÇÃO!**

Ao abrir uma reclamação, o seu problema pode ser resolvido em até 30 dias! Já com nossa equipe de atendimento, é MUITO mais RÁPIDO!



(11) 9.5218-0436

SEG. A QUIN. 9H ÀS 18H  
SEX. 9H ÀS 17H



ENGLISH

Headset Gamer Wireless

HZ-K21



FEATURES

- 1+3 press the button "+" in the music state to increase the volume press the button "-" in the music state to decrease the volume short press the middle position in the music state to pause
- 2 red backlit logo (working and charging indication)
- 4 microphone transmitter
- 5 USB charging port
- 6 power on/off
- 7 line-in (when the headset is out of power, plug in the audio cable to use as a wired headset)
- 8 microphone on/off

INSTALLATION

- 1. Power on: Turn the power switch to "ON" state, the headset power if on, then the power indicator will light on and flash. This state means the USB transmitter is not connected and wait to be connected.
  - 2. Plug the USB transmitter directly into the USB port of the device. Then the indicator of the transmitter and the headset are always on. Indicate that they are connected successfully.
  - 3. Power off: Turn the power switch to "OFF" state, the headset power is off, then the headset power indicator will go out and save the battery power to the maximum extent.
- Note: The transmitter should be away from the wireless network card, BT device, other 2.4 GHz devices.

CHARGING BATTERIES

The headset battery is not fully charged when it leaves the factory. Therefore, please fully charge the headset for 10 hours before use. For next charge, only takes about 3.5 hours to fully charge. The charging cable should be plugged into headset. When charging, the light-emitting bit indicator is always on and when it is fully charged, the indicator is off. When you hear "BEEP" while using the headset, you are reminded that the battery is low and needs to be recharged. When you have not used the headset for a long time, the battery may cause excessive discharge. You must charge the headset for more than 4 hours, but not more than 24 hours. Note: Some chargers may also come with a USB port that allows the headset to be charged with a 5V 1000 MA charger. But please do not exceed this value, otherwise it will easily damage the headset.

HEAD ADJUSTMENT

Freely adjust the retractable card slots on both sides before wearing, which makes you more comfortable and easier.

MICROPHONE

Hidden high-quality omnidirectional microphone design, which can be folded back without occupying space during use.

CONDITIONS OF CARRIAGE

It is forbidden to throw the goods or drop the goods down. If the goods are in a place with high humidity, it's recommended to use protective covers against moisture. It is forbidden to put more than 4 pieces of packagings on top of each other.

This device meets the basic requirements and other relevant conditions of the appropriate European Directives.

This device complies with Part 15 of the FCC Commission Rules. A operation is subjected to the following two conditions:  
(1). This device may not cause harmful interference (2). This device has to accept any received interference including interference that may cause undesirable action.

This symbol indicates that the product shall not be treated as domestic waste. It should be handed over to the relevant collection centre for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Restriction Of Hazardous Substances (lead, mercury, hexavalent chromium, cadmium, polybrominated biphenyls, polybrominated diphenyl ether).



TROUBLESHOOTING

- 1. Headset without sound
  - check the connection between the headset and the transmitter and plug the transmitter into another USB port on computer
  - close and re-open the multimedia player
  - check if the power is insufficient and use it after charging
- 2. The transmitter indicator light flashes slowly and headset without sound
  - re-plug the transmitter, when the headset is turned on, press and hold the middle button on the headset (3) for more than 5 seconds, the light-emitting indicator fast flashing and into the factory setting state. When the headset light-emitting indicator keep light on it can be used normally
- 3. Short receiving distance
  - check if there is wireless network card interference, please keep the transmitter away from wireless interference
  - check if there is equipment of the same frequency nest to the transmitter, please avoid the same frequency equipment
  - the receiving distance is related to the environment and the distance may be affected in some environments
- 4. Volume is too high
  - reduce the volume due to the PC setting or another portable device

PACKAGE CONTENTS

1 x wireless gaming headset H4, 1 x USB transmitter, 1 x micro USB charging cable, 1 x 3.5 mm audio cable, 1 x user manual

PRECAUTIONS

In order to get the best sound quality of the headset, please wear the headset correctly. Please listen to music at an appropriate volume to prevent adverse effects on your hearing. The L marked by the headset is the left side and R is the right side. Do not rotate the headset vigorously. Do not disassemble the headset yourself. Do not use this product in an environment where it is exposed to liquid or moisture. Do not operate this product when the temperature exceeds the specified range to 40°C. Use dry soft cotton products for cleaning the headset.

MAINTENANCE

Do not expose the headphones to strong impacts, handle carefully with headphones. Do not place any objects on the headphones, the pressure can deform them. Fouling of the membrane can cause worse sound quality. Frequent use may cause worse quality of headphones' surface.

CONDITIONS OF GUARANTEE

The warranty period begins from the date of purchase. In case of a defect, contact please a salesperson with a detailed description of the defect, purchase invoice and all accessories. In case of missing parts such as: manual, software or other parts, please contact the salesperson, as well. The warranty expires in case of any changes of the product, mechanical damage, use for purposes other than intended, repairs performed by a third party and negligence.

展开尺寸: 297X210 MM 128g铜版纸 钱包折, 折两下